





Accessories Care Guide

www.BOCCHIUSA.com





BOCCHI

WORKSTATION ACCESSORIES

Available in several styles and sizes to fit our wide range of kitchen sinks.

Made of solid sapele wood and stainless steel





CLEAN your accessories immediately after each use. Wipe clean with a damp cloth, or wash using dish soap. Rinse with water to remove all debris and soap. Dry thoroughly. If letting air dry, set accessories with wooden parts on edge to aid in proper draining. Stainless Steel bowls and non-wooden parts are dishwasher safe.

STORE your accessories by either setting into place on your workstation sink, or by standing vertically. Be careful to avoid water <u>damage to the wooden</u> areas from splashing if storing in the sink.

MAINTAIN the beauty of your wood finishes by rubbing a food-grade cutting board oil, mineral oil or vegetable oil into all sides of the boards as needed to prevent over drying.

- Don't use bleach or harsh cleaning agents
- Don't leave wooden parts soaking or sitting in water
- Don't put wooden parts into the dishwasher; non-wooden parts such as stainless steel are dishwasher safe
- Don't expose wooden parts to hot surfaces or prolonged, direct sunlight to avoid warping

Proper care of your workstation accessories is important. Many feature natural wood products and improper care can lead to warping or cracking; damages resulting from improper care are not covered by warranty. Please follow these care instructions carefully.